

How to upgrade my drive?


This manual shows you how to upgrade your drive with the Philips DVD ReWriter Upgrade tool.




Philips Consumer Electronics
Version 06

PHILIPS


1 Start the Upgrade Tool you downloaded.
Click "OK"




2 Choose the drive to upgrade and click "Upgrade".



3 Click "OK" to confirm.



4 Your drive is being upgraded.
Do not interact with the system.



5 Your drive is now upgraded.
Click "OK" to exit the upgrade program.
Your system will be restarted.

