

## 声卡安装指南(CT5880) V1.0

如果您想安装声卡驱动，我们建议您使用 ‘Creative Vibra 128 installation CD’ 来安装，此为最新版本。

### 安装声卡驱动:

- 1.将 CD 盘放入 CD-ROM 光驱中
- 2.安装程序会自动执行
- 3.选定要安装的程序点击 “OK” 即可

If you want to install audio driver, we recommend to use ‘Creative Vibra 128 installation CD’. This version is latest.

### To install Audio Driver:

- 1.Place disc into CD-ROM driver
- 2.Autoplay installation starts automatically
- 3.Select application to install and click ‘OK’

