

How to upgrade my drive?


This manual shows you how to upgrade your external drive.




Philips Consumer Electronics
Version 02

PHILIPS


- 1 Start the Update Tool you downloaded.
Click "Yes"



- 2 Choose the drive to update and click "Update".



- 3 Your drive is being updated.
Do not interact with the system.



- 4 Your drive has been updated.
Click "OK" to exit the update program.

